Motion

TREKKER

AEROLITE

Parts List

Contents

Upper
Page 3

Lower
Page 4

Batteries
Page 5

Upper Parts	Part Number
1 Joystick Controller	AE.105
2 Unlock Handle Assembly	AE.149
3 Fold Locking Mechanism	AE.151
4 Seat Cushion Backing	AE.152
5 Seat Cushion	AE.153
6 Backrest with Foam	AE.154
7 Backrest Tube Cover	AE.155
8 Backrest Backing	AE.156
9 Backrest Cushion	AE.157
10 Backrest Backing Block	AE.158
11 Armrest Pad	AE.159
12 Quick Release Pin	AE.160
13 Armrest Joint Patch	AE.161
14 Armrest Assembly Left	AE.163
15 Armrest Assembly Right	AE.164
16 Armrest Front Assembly	AE.165
17 Armrest Sleeve & Gasket	AE.170

Lower Parts	Part Number
18 Brushless Motor Right	AE.135
19 Anti-Tip Wheel Right	AE.136
20 Anti-Tip Wheel Left	AE.137
21 Brushless Motor Left	AE.138
22 8” Front Wheel	AE.142
23 Front Fork	AE.143
24 Footrest Complete	AE.144
25 Climber Wheel Set	AE.145
26 Footrest Stickers	AE.146
27 Shopping Bag	AE.147
28 Outer Cover Plug	AE.148
29 Front Wheel Cover	AE.150
30 Main Controller	AE.162
31 Mudguard Left Hand	AE.167
32 Mudguard Right Hand	AE.168
33 Scratch Resistant Cover	AE.169

Battery Parts	Part Number
34 12ah Lithium Battery Pack	AE.106
35 Battery Charger	AE.107
36 Battery Case Cover	AE.133
37 EU Battery Charger	AE.134
38 Dual Battery Socket Set	AE.139
39 Spare Battery Clip	AE.141